## **ASSP**

# LOW NOISE AMPLIFIER (2 CIRCUITS)

## **MB54502**

#### **■ DESCRIPTION**

The Fujitsu MB54502 includes two independent amplifiers which are used for mobile telecommunication applications such as handy phones and car phones. Both of the amplifiers achieve low current consumption as well as the low noise performance. Using Fujitsu's advanced technology, MB54502 achieves an Icc of 2mA typ. respectively (total 4mA typ.).


#### **■ FEATURES**

· Supply voltage 3V (typ.) Current consumption 2mA (typ.) Input frequency 1.1GHz (max.) • Gain 14dB (typ.)\*1 2.2dB (typ.)\*1 Noise figure • 1dB compression point -6dBm (typ.)\*1 2.5dB (typ.)\*1 Frequency tolerance · Input return loss 8dB (typ.)\*1 Output return loss 8dB (typ.)\*1

\*1: Measured by the circuit of "measurement circuit example". (fin = 820MHz)


• 16-pin Plastic Shrink Small Outline Package (Suffix: -PFV)

#### **■ PACKAGE**



### MB54502

#### **■ PIN ASSIGNMENT**




#### ■ ABSOLUTE MAXIMUM RATINGS

Parameters	Symbol	Value	Unit
Supply Voltage	Vcc	-0.5 to 7.0	٧
Output Voltage	vage Vo −0.5 to Vcc + 0.5		V
Output Current	lo	0 to 10	mA
Storage Temperature	Тѕтс	-55 to +125	°C

Note: Permanent device damage may occur if the above Absolute Maximum Ratings are exceeded. Functional operation should be restricted to the conditions as detailed in the operational sections of this data sheet. Exposure to absolute maximum rating conditions for extended periods may affect device reliability.

#### **■ EQUIVALENT CIRCUIT**



#### **■ PIN DESCRIPTION**

Pin No.	Pin Name	Description	Pin No.	Pin Name	Description
1	Rext1	Emitter (amplifier 1)	9	RFin2	Input (amplifier 2)
2	Lext1	Load connection (amplifier1)	10	GND	Ground
3	RFout1	Output (amplifier 1)	11	GND	Ground
4	GND	Ground	12	Vcc2	Power supply (amplifier 2)
5	NC	No connection	13	NC	No connection
6	RFout2	Output (amplifier 2)	14	Vcc1	Power supply (amplifier 1)
7	Lext2	Load connection (amplifier 2)	15	GND	Ground
8	Rext2	Emitter (amplifier 2)	16	RFin1	Input (amplifier 1)

3

### MB54502

#### ■ RECOMMENDED OPERATING CONDITIONS

Parameter	Symbol		Unit		
Farameter		Min.	Тур.	Max.	Onit
Supply Voltage	Vcc	2.7	3.0	5.5	V
Input Voltage	Vı	GND		Vcc	V
Operating Temperature	Та	-40		+85	°C

Notes: To protect against damage by electrostatic discharge, note the following handling precautions:

- Store and transport devices in conductive containers.
- Use properly grounded workstations, tools, and equipment.
- Turn off power before inserting or removing this device into or from a socket.
- Protect leads with conductive sheet, when transporting a board mounted device.

#### **■ ELECTRICAL CHARACTERISTICS**


 $(Vcc1 = +3.0V, Vcc2 = 0.0V, Ta = 25^{\circ}C$ or  $Vcc1 = 0.0V, Vcc2 = +3.0V, Ta = 25^{\circ}C)$ 

Parameter	Symbol	Conditions	Target Value			l lm:t
			Min.	Тур.	Max.	Unit
Supply Voltage	Vcc	_	2.7	3.0	5.5	V
Supply Current	Icc	1 amplifier active		2.0		mA
Operating Frequency	fin	_		820	1100	MHz
Gain	Gain			14	_	dB
Noise Figure	NF			2.2	_	dB
1dB Compression Point	P <sub>1dB</sub>	Output		-6	_	dBm
Amplitude Tolerance	_	820 ± 50MHz		2.5	_	dB
Input Return Loss	RLin			8	_	dB
Output Return Loss	RLоит			8		dB


**Remark:** Electrical characteristics depend on external circuits (elements) or status of mounting. The above characteristics are measured by the test circuit in the next page.

## MB54502

#### **■ MEASUREMENT CIRCUIT (EXAMPLE)**



#### **■ PACKAGE DIMENSIONS**



### **FUJITSU LIMITED**

For further information please contact:

#### Japan

FUJITSU LIMITED
Corporate Global Business Support Division
Electronic Devices
KAWASAKI PLANT, 4-1-1, Kamikodanaka
Nakahara-ku, Kawasaki-shi
Kanagawa 211-88, Japan

Tel: (044) 754-3753 Fax: (044) 754-3332

#### **North and South America**

FUJITSU MICROELECTRONICS, INC. Semiconductor Division 3545 North First Street San Jose, CA 95134-1804, U.S.A.

Tel: (408) 922-9000 Fax: (408) 432-9044/9045

#### **Europe**

FUJITSU MIKROELEKTRONIK GmbH Am Siebenstein 6-10 63303 Dreieich-Buchschlag Germany

Tel: (06103) 690-0 Fax: (06103) 690-122

#### **Asia Pacific**

FUJITSU MICROELECTRONICS ASIA PTE. LIMITED No. 51 Bras Basah Road, Plaza By The Park, #06-04 to #06-07 Singapore 189554 Tel: 336-1600

Fax: 336-1609

#### All Rights Reserved.

Circuit diagrams utilizing Fujitsu products are included as a means of illustrating typical semiconductor applications. Complete information sufficient for construction purposes is not necessarily given.

The information contained in this document has been carefully checked and is believed to be reliable. However, Fujitsu assumes no responsibility for inaccuracies.

The information contained in this document does not convey any license under the copyrights, patent rights or trademarks claimed and owned by Fujitsu.

Fujitsu reserves the right to change products or specifications without notice.

No part of this publication may be copied or reproduced in any form or by any means, or transferred to any third party without prior written consent of Fujitsu.

The information contained in this document is not intended for use with equipments which require extremely high reliability such as aerospace equipments, undersea repeaters, nuclear control systems or medical equipments for life support.

#### F9505

© FUJITSU LIMITED Printed in Japan